



ALPHAPOINT

TECHNICAL DATA SHEET

AlphaPoint Flexible Pointing has been specially designed for use in construction applications, where advantage can be taken of its excellent adhesion and water resistance.

AlphaPoint Flexible Pointing is available in a variety of colours and is trowel applied to re-point concrete or terracotta ridge capping.

AlphaPoint RapiDry is a spray-on solution that can be applied onto surfaces where AlphaPoint Flexible Pointing has been applied if rain is imminent and faster set times are required. Please note that RapiDry will only set the outside layer of the pointing.

FEATURES & BENEFITS

- Fade resistant colour.
- Long service life.
- No staining by leaching cement salts.
- Waterproofing the key tile joints.
- Eliminates leaking ridges and discoloured pointing.
- Water wash up.

HEALTH & SAFETY

- **Contact Poisons Information Centre (Phone Australia: 13 11 26) or a doctor.**
- **IF SWALLOWED:** Rinse mouth. Do NOT induce vomiting.
- **IF ON SKIN:** Wash with plenty of soap and water.
- **IF INHALED:** Remove victim to fresh air and keep at rest in a position comfortable for breathing.
- **IF IN EYES:** Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.
- **IF EXPOSED OR CONCERNED:** Get medical advice/attention.
- Wear appropriate protective clothing, gloves, eye/ face protection and suitable respirator.

DISCLAIMER: The recommendations and data provided in this document are true and accurate at the time of testing. The information is given in good faith but without any guarantee as conditions and methods of use on the Alphaglaze product are beyond Alphaglaze's control. Alphaglaze recommends that the applicator of this product conducts a small test patch in an inconspicuous area to determine the suitability of the Alphaglaze material and its recommendations prior to use or application.

RECOMMENDATIONS & PRECAUTIONS

- Use this product in a well-ventilated area.
- Ensure that the application of the product is in accordance with Alphaglaze recommendations.
- Due care and consideration should be taken where water collection methods are present. Alphaglaze recommends allowing 10 days curing and an initial rinse (rain or tap water wash) prior to reconnecting water collection systems.
- The surface preparation is the responsibility of the Builder, Renovator, Contractor or Applicator. It is also the responsibility of the Applicator to ensure that the substrate is of an acceptable standard prior to the application of the Alphaglaze Coating System.